

HF6.XXX DRUCK-/ FÜLLSTANDSTRANSMITTER

Hydrostatischer Füllstand/Druckmessumformer



Artikel	product.detail.attribute.[["Applications\ / Operative Range"]
HF6.004	0-400 mbarg]
HF6.010	0-1000 mbarg]
HF6.100	0-10 barg]
HF6.160	0-16 barg]