

# M9.50.PX – M9.50.WX

Controller übertragen.



Artikel	Montage	Stromversorgung	Sensoreingang	product.detail.attribute.Output
M9.50.P1	Panel	12 - 24 VCC	Flow (Frequency)	2*(S.S.R.) \$ 2*(mech. relay)
M9.50.W1	Wall	12 - 24 VCC	Flow (Frequency)	2*(S.S.R.) \$ 2*(mech. relay)
M9.50.W2	Wall	110 - 230 VCA	Flow (Frequency)	2*(S.S.R.) \$ 2*(mech. relay)